

JET

JSG-96


JSG-96.....708595M.....1~230V, 50Hz

PARTS LIST

Walter Meier (TOOL) AG
Tämperlistrasse 5
CH-8117 Fällanden
Switzerland
Phone +41 44 806 47 48
Fax +41 44 806 47 58
jetinfo.eu@waltermeier.com
www.jettools.com

CE

JSG-96 Disc Sander Assembly




JSG-96 Disc Sander Assembly

Index	Part		Description	Size	Qty.
1	JSG96-101A		Base		1
2	JSG96-102E		Motor		1
	JSG96-102AE		Starting Capacitor (not shown).....		1
	JSG96-102BE		Running Capacitor (not shown).....		1
3	TS-1550041		Flat Washer	M6.....	4
4	TS-1551041		Lock Washer	M6.....	7
5	TS-1540041		Hex Nut.....	M6.....	1
6	JSG96-106		Disc Cover.....		1
7	JSG96-107		Screw w/Washer	1/4x3/8.....	3
8	JSG96-108		Air Controller		1
9	JSG96-109		Tap Screw	1/4x1/2.....	2
10	JSG96-110		Lock Knob		1
11	JSG96-111		Rivet		1
12	JSG96-112		Key	5x5x25	1
13	JSG96-113		Disc.....		1
14	JSG96-114		Set Screw	#10x3/8.....	1
15	JSG96-115E		Sanding Disc		1
16	JSG96-116		End Cover		1
17	JSG96-117		Pin		1
18	JSG96-118		Compound Table		1
19	JSG96-119		Table Bracket		1
20	JSG96-120		Trunnion		2
21	JSG96-121		Pin		2
22	JSG96-122		Hex Socket Cap Screw	#10x5/8.....	2
23	JSG96-123		Table Support w/Scale		1
24	TS-0680031		Flat Washer	5/16.....	2
25	TS-0051021		Hex Head Screw	5/16x5/8.....	2
26	JSG96-126		Lock Handle		1
27	JSG96-127		Screw.....	1/4x3/8.....	1
28	JSG96-128		Pointer		1
29	TS-0270031		Set Screw	5/16x3/8.....	2
30	JSG96-130		Rod		1
31	JSG96-131		Set Screw	1/4x1	1
32	TS-0561011		Hex Nut.....	1/4.....	1
33	JSG96-133		Lock Handle	5/16x1	1
35	JSG96-135E		Switch		1
36	JSG96-136A		Plate		1
37	JSG96-137A		Tap Screw	3/16x3/8.....	19
38	TS-0680011		Flat Washer	3/16.....	5
39	JSG96-139E		Strain Relief.....		1
40	JSG96-140E		Power Cord		1
41	JSG96-141		Dust Chute		1
42	JSG96-142		Circle Gauge		1
43	JSG96-143		Tip.....		1
44	JSG96-144		Set Screw	1/4x1/4	2
45	JSG96-145		Set Screw	M4x6.....	1
46	JWBS18-403		Miter Gauge Body		1
47	JSG96-147		Guide Bar		1
48	JWBS18-401		Lock Handle		1
49	JWBS20-156		Guide Disc		1
50	JSG96-150		Pan Head Screw	1/4x5/16	1

JSG-96 Disc Sander Assembly

Index	Part		Description	Size	Qty.
No.	No.				
51	JSG96-151		Screw.....	#10x5/16.....	1
52	JWBS18-406		Pointer	1
53	JSG96-153		Cord Protector	1
54	JSG96-154E		I.D. Label	1
55	JSG96-155		Indication Label	1
56	JSG96-156		Roll Pin	1
57	JSG96-157E		Motor Label	1
58	JSG96-158		Holder-Small (Running Capacitor)	1
59	JSG96-159		Holder-Big (Starting Capacitor)	1
60	JSG96-160		Plate	1
61	JSG96-161		Tap Screw	3/16x5/8.....	2
62	JSG96-162		Screw.....	1/4-20x1/2.....	1
63	JSG96-163		Screw.....	#10-24x5/16.....	1
64	JSG96-164		Tooth Washer.....	1
65	JSG96-165		Tap Screw	M4X15	2
66	JSG96-166		Tap Screw	1/4"x3/8"	4
	JSG96-MGA		Miter Gauge Assembly (Items 38, 46 thru 52)	1
	JSG96-CGA		Circle Gauge Assembly (Items 42 thru 45)	1

JSG-96 Belt Sander Assembly




JSG-96 Belt Sander Assembly

Index	Part		Description	Size	Qty.
1	JSG96-201		Bracket		1
2	TS-0208071		Hex Socket Cap Screw	5/16x1-1/4.....	1
3	JSG96-203		Pin		1
4	JSG96-204		Fixed Plate		1
5	TS-0680021		Flat Washer	1/4.....	8
6	JSG96-206		Screw.....	1/4x3/8.....	3
7	JSG96-207		Key	5x5x70	1
8	JSG96-208		Drive Drum		1
9	JSG96-209		Lock Nut	5/8-18UNF	1
10	JSG96-210		Belt Support.....		1
11	JSG96-211		Hex Socket Cap Screw	5/16x5/8.....	4
12	TS-0720081		Lock Washer	5/16.....	5
13	TS-0680031		Flat Washer	5/16.....	6
14	TS-0270031		Set Screw	5/16x3/8.....	4
15	JSG96-215		Bracket		1
16	TS-0208061		Hex Socket Cap Screw	5/16x1	1
17	TS-0561021		Hex Nut.....	5/16.....	1
18	JSG96-218		Rod		1
19	JSG96-219		Pad		1
20	JSG96-220		Set Screw	1/4x3/8.....	1
21	JSG96-221		Follow Roller.....		1
22	BB-6201ZZ		Ball Bearing		2
23	JSG96-223		C-Ring	STW-11	2
24	JSG96-224		Shaft		1
25	JSG96-225		Bushing.....		1
26	TS-0680041		Flat Washer	3/8.....	1
27	JSG96-227		Lock Nut	3/8.....	1
28	JSG96-228		Roll Pin	4x20	1
29	JSG96-229		Support Bracket.....		1
30	JSG96-230		Micro-Adjusting Seat		1
31	TS-0207021		Hex Socket Cap Screw	1/4x1/2	6
32	JSG96-232		Screw.....		1
33	JSG96-233		Adjusting Knob		1
34	JSG96-234		Spring		1
35	JSG96-235		Lock Nut	M6.....	1
36	JSG96-236		Washer		2
37	JSG96-237		Disc Spring		2
38	JSG96-238		Lock Handle		1
39	JSG96-239		Roll Pin	3x20	1
40	JSG96-240		Spring		1
41	JSG96-241		Eccentric Handle		1
42	JSG96-242		Hex Socket Cap Screw	1/4x1-1/4.....	1
43	JSG96-243		Lock Nut	1/4.....	2
44	JSG96-244		Air Controller (Belt).....		1
45	JSG96-245		Dust Chute		1
46	JSG96-246E		Hex Head Bolt	1/4x1/2	1
47	JSG96-247		Flat Washer	1/4x3/4	3
48	JSG96-248		Back Cover		1
49	JSG96-249		Sanding Belt		1
50	JSG96-250		Belt Table		1
51	JSG96-251		Trunnion		2
52	TS-0050021		Hex Socket Cap Screw	1/4x5/8.....	2
53	JSG96-253		Guide Pin.....		2

JSG-96 Belt Sander Assembly

Index	Part		Description	Size	Qty.
No.	No.				
54	TS-0561011		Hex Nut.....	1/4.....	2
55	JSG96-255		Set Screw	1/4x3/4	2
56	JSG96-256		Lock Handle	5/16x1-1/4.....	2
57	JSG96-257		Graphite Pad		1
58	JSG96-155		Indication Label		1
59	JSG96-259E		Loosen/Tighten Label.....		1
60	JSG96-260		Flat Washer	1/4x9/16x1/8	2
61	JSG96-261		Serrated Plate		2
62	JSG96-262		Phillips Tap Screw	M3x10	4
63	JSG96-263		Lock Washer	1/4.....	1
64	JSG96-264		Set Screw	1/4x1-1/2.....	1
65	JSG96-265		Left Cover		1
66	JSG96-266		Right Cover		1
67	JSG96-267		Rod		1
68	JSG96-268		Flat Washer	3/8.....	1
69	JSG96-269		Lock Nut	3/8.....	1


JSG-96 Closed Stand Assembly



JSG-96 Closed Stand Assembly

Index	Part			
No.	No.	Description	Size	Qty.
1	JSG96-301	Base		1
2	JSG96-302	Lock Nut	3/8.....	4
3	PJE-S05	Wheel		4
4	JSG96-304	Hex Head Screw	3/8x2-1/2.....	4
5	JSG96-305	Shaft		1
6	PJN-S04	Eccentric Cam		2
7	JSG96-307	Set Screw	M6x10.....	2
8	JSG96-308	Spring		2
9	JSG96-309	Roll Pin	4x16.....	2
10	PJN-S02	Foot Brake		1
11	JSG96-311	Lock Nut	M10x1.5.....	1
12	TS-0720091	Lock Washer	3/8.....	4
13	TS-0680041	Flat Washer	3/8.....	4
14	JSG96-314	Tool Shelf		1
15	TS-0060031	Hex Head Screw	3/8x3/4.....	1
16	JSG96-316	Washer	3/8x1-1/8.....	1
17	JSG96-317	JET Plaque		1
18	JSG96-318	Door		1
19	JSG96-319	Latch		1
20	JSG96-320	Screw	M3x4.....	2
21	JSG96-321	Door Pivot		1
22	JSG96-127	Screw	1/4x3/8.....	2
23	TS-0561011	Hex Nut	1/4.....	2
24	JSG96-324	Braking Label		1
25	TS-0561031	Hex Nut	3/8.....	4
26	TS-0060131	Hex Head Screw	3/8x3.....	4

JSG-96.....708595M.....1~230V, 50Hz



	colour of strands	Litzenfarben	couleur des cordons
BK	black	schwarz	noir
WH	white	weiß	blanc
BU	blue	blau	bleu
YE	yellow	gelb	jaune
RD	red	rot	rouge
BN	brown	braun	brun
GY	grey	grau	gris
GNYE	green-yellow	grün-gelb	vert-jaune
OG	orange	orange	orange
VT	violet	violett	violet

	meaning of symbol	Bedeutung der Zeichen	Interpretation
M	motor	Motor	moteur
S	switch	Schalter	interrupteur
C	condenser	Kondensator	condensateur
E	electronic unit	Elektronik Einheit	unité électronique
F	fuse	Sicherung	fusible
RS	reversing switch	Drehrichtungsschalter	commu. droite/gauche
CS	centrifugal switch	Fliehkraftschalter	déclencheur centrifuge
OL	overload cut-off	Überlastschutzschalter	déclencheur surcharge
LS	limit switch	Positionsschalter	micro

